



RECOATING PROCEDURE GUIDELINE – Timbakote Coatings Rustic System

Description:

Timbakote Coatings Rustic System is a tough, acrylic film-forming stain designed for New Zealand's harsh conditions. It has excellent adhesion on many substrates including engineered timber (ply) or composite timber, fibre cement and other cementitious substrates. All Timbakote Coatings are environmentally friendly and certified by Eco Choice Aotearoa.

Features:

- Highly durable acrylic coatings
- Natural looking finish
- Manufactured in NZ for our harsh environmental conditions
- Available in 24 different colours to refresh or update your cladding

Use:

Ideal for recoating and rejuvenating the natural look of Innowood exterior composite timber cladding, screening etc. *Always conduct an adhesion test on a discrete area before use.

Precautions and Limitations:

- Remove any discolouration from the surface of the substrate with using a light sand.
- Do not apply to hot surfaces in direct sunlight as doing so will result in difficult application, poor adhesion. and possible blistering.
- Do not apply in temperatures above 35°C, below 10°C or if rain or dew is expected within 4 hours of application.

Surface Preparation:

Treat any moss, mould, and lichen with a dilute Sodium Hypochlorite solution, then rinse thoroughly. Remove all loosely bound coatings by way of sanding. Sharp edges must be sanded, nail holes and minor defects to be filled with suitable timber filler. Re-wash cladding with warm soapy water and rinse thoroughly to remove any prior to coating application.

Application:

Stir well before and during use with a flat stirrer. Apply 1 coat Timbakote Rustic Basecoat with a good quality paintbrush, applicator pad, roller or spraygun. Thinning is not generally recommended, as it can be detrimental to the coating performance. However, the addition of up to 50mls of water per litre maybe required in hot weather or when coating absorbent surfaces. Then apply 2-3 coats of Timbakote Timber Pro in the chosen colour to achieve the desired effect. Best results are achieved using a paint brush or speed brush. Do not over spread, as achieving the correct film build is important to the life of semi-transparent coatings.



Coverage:

10-12sqm/litre

Drying Times:

Depending on such factors as film thickness, ambient air temperatures, humidity levels and air circulation. The general dry times at 10-12sqm/litre are

Touch dry: 30 minutes

Recoat time: 2 hrs

Curing time: 7 days

Clean Up:

All equipment can be cleaned up in water.

Health And Safety:

Wear impervious gloves and wash paint deposits off skin with soap and water.

Moderately irritating to eyes- wear splash proof goggles to protect eyes.

Flush eyes immediately with plenty of water if coating splashes to the eyes occur.

If discomfort persists, seek medical attention. Keep out of children's reach.

Ingestion: Give 1-3 cups of water and seek medical attention.

Disposal

Let residual product dry by leaving the lid off the container. Dispose with refuse if permitted by local council. Paint containers are reusable for non-food purposes and recyclable in areas where recycling and collection facilities are available.

Material Safety Data Sheet -

<http://www.timbakote.co.nz/site/timbakote/Timbakote%20Timber%20Pro%20MSDS.pdf>

For Product Data Sheet please contact Timbakote Coatings Ltd 0800 846 225