E4SL90

Single **S**teel Frame

Load Bearing

Two Way FRR

4 Layers: 2 Layers of Plasterboard to each side of frame

System Number	Lining Suffix	Fire Rating	Load Bearing Ability	Noise Control		Lining Requirement	
				STC	Rw	Lilling Requirement	
E4SL90	-F64	90/90/90	LB	47	46	2 x 16mm Elephant FireSmart on One side 2 x 16mm Elephant FireSmart to Other side	

Framing

Any steel frame designed to meet structural criteria for strength and serviceability under dead and live loads. Stud width shall be 35mm minimum. Stud spacing at 600 centres maximum.

Frame heights as determined by specific design.

Plasterboard Lining

Two layers of 16mm Elephant FireSmart lining on each side of the steel framing. Vertical or Horizontal fixing permitted. Use full height or full length sheets where possible.

For Vertical Fixing- the vertical sheet joints must be offset on the opposite side of the frame.

For Horizontal Fixing- the horizontal sheet joints must be formed over nogs and must be offset on the other side of the frame.

Sheet end butt joints- must be formed over framing and staggered. Offset joints from opposite side of the frame.

All outer layer joints must be staggered from inner layer joints.

All sheet joints must be formed over framing.

The layers are fixed hard to the floor.

Sheets shall be touch fitted.

Fixing of Linings

Fasteners

	Side	One	Side Two					
System Number	1st Layer	2 nd Layer	1 st Layer	2 nd Layer				
	Self-Tapping Drywall Screws							
E4SL90-F64	16mm	16mm	16mm	16mm				
E43L9U-F04	32 x 6g	51 x 7g	32 x 6g	51 x 7g				

Fastener Centres

Inner Layer: Fix at $600\,\mathrm{mm}$ centres up each stud with no fixing to top and bottom track sections.

Outer Layer: Fix at 300mm centres up each stud with no fixing to top and bottom track sections.

Place fasteners no closer than 12mm to the sheet edge and 50mm from sheet ends

Place fasteners at 200mm centres where sheet end butt joints occur. Avoid outer layer screws from hitting inner layer screws.

Jointing

Inner Layer: Unstopped

Outer Layer: All fastener heads stopped and all sheet joints reinforced with paper jointing tape and stopped. All in accordance with Elephant Plasterboard Installation Guide.



