

Maintenance for the Asona Fabric Wrapped Panels

UPKEEP

Asona fabric wrapped acoustic ceiling & wall panels are interior finishes and designed for installation & operation within normal environmental conditions of temperature and humidity (ref: datasheets). Handling of ceiling panels shall be by a competent trained person. We recommend clean white gloves be worn when handling the panels. Removed panels should be stacked face to face to prevent marking before returning to their original location.

PRODUCT TYPE: Textile fabric, non-pile

REGULAR CARE:

Protect from direct sunlight

• Vacuum regularly using low suction

SPOT CLEANING:

- Treat spills and stains as soon as possible
- Gently scrape any soil or mop any liquid from the surface of the fabric
- Do not scrub
- · Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill
- Do not saturate the fabric or interior with water or other cleaning liquids
- May be spot cleaned with dry-cleaning solvent

CLEANING

- DO NOT REMOVE FABRIC FROM PANELS
- Clean with hot water extraction machine (hot)
- Professional cleaning recommended Do not use dishwashing or laundry detergents
- Use only upholstery detergent
- Do not wet panel
- Dry in shade away from direct heat and sunlight
- Allow to dry thoroughly before re-use
- Wipe gently, do not rub

Dust and loose dirt may be removed using a brush or with a vacuum cleaner. Vacuum cleaner attachments such as those designed for cleaning upholstery or walls do the best job. Be certain to clean in one direction only. This will prevent rubbing dust into the surface of the panel.

A damp soapy sponge may be used but should contain as little water as possible, gently wipe the affected area and wipe with clean damp cloth and dry immediately.

Panels with stubborn stains or penetration damage should be removed from the wall or ceiling and returned to Asona for re-covering and repair.