


INSTALLATION SHEET/ TRACKLOK SPT-10



- 1/ Set out head track (clamp or screw temporarily).
- 2/ Measure TRACKLOK™ SPT-10 placements (refer to TRACKLOK™ specification sheet).
- 3/ Create 30-40mm hole in tile with holesaw (pilot bit must spike head section).
- 4/ Enlarge pilot hole in head track to 9mm
- **5/** Bolt TRACKLOK™ SPT-10 to head track using washer and bolt provided.
- 6/ Measure distance to slab and cut your brace material to length as per chart provided.
- 7/ Connect bracing material to TRACKLOK™ SPT-10 fly brace and top plates.
- **8/** Fix TRACKLOK[™] SPT-10 top plates to slab with approved masonry anchor.
- 9/ Remove temporary fixings.


For further installation and limitation information please refer to TRACKLOK™ SPT-10 Specification Sheet available on website.







INSTALLATION SHEET/ TRACKLOK SPT-10



DISTANCE TO SLAB/

EACH BRACING LENGTH/

200mm	183mm
300mm	325mm
400mm	466mm
500mm	605mm
600mm	750mm
700mm	890mm
800mm	1035mm
900mm	1175mm
1000mm	1315mm
1100mm	1455mm
1200mm	1595mm
1300mm	1735mm



