## BARRICADE FR FIRE RETARDANT - BUILDING WRAP SPECIFICATION GUIDE



V2.0 March 2024



## 1. GENERAL

1.1	PRODUCT DESCRIPTION	Barricade FR Wrap is a non-woven fire retardant, water resistant, breathable synthetic wall underlay for use under direct fixed and non-direct fixed wall cladding on timber framed and steel framed buildings. The product is manufactured from high quality synthetic spun bonded material with high UV qualities.
1.2	PHYSICAL PROPERTIES	<ul> <li>Barricade FR is a non-woven breathable composite building wrap. The following tests have been carried out in accordance with NZBC Acceptable Solution E2/AS1 Table 23:</li> <li>Tensile strength, edge tear resistance and resistance to water vapour transmission in accordance with ASNZS 4200.1</li> <li>Resistance to water penetration in accordance with AS/NZS 4201.1.4</li> <li>Surface water absorbency in accordance with AS/NZS 4201.6</li> <li>Air resistance to BS 6538.3</li> <li>Shrinkage in accordance with AS/NZS 4201.3</li> <li>pH of extract in accordance with AS/NZS 1301.421s</li> <li>Fire retardant in accordance with AS1530 Part 2 Flammability</li> </ul>
1.3	COMPATIBILITY	<ul> <li>Barricade FR has been appraised for use as a flexible wall underlay on timber framed buildings within the following scope:</li> <li>The scope limitations of NZBC Acceptable Solution E2/ AS1, Paragraph 1.1; and,</li> <li>With absorbent and non-absorbent wall claddings directly fixed to the frame; and,</li> <li>With absorbent and non-absorbent wall claddings installed over an 18mm minimum drained cavity; and,</li> <li>With masonry veneer in accordance with NZBC Acceptable Solution E2/AS1; and,</li> <li>Situated in NZS 3604 wind zones up to and including 'Very High'</li> </ul>



	<ul> <li>Barricade FR has been appraised for use as a flexible wall underlay on steel framed buildings within the following scope:</li> <li>The scope limitations of NZBC Acceptable Solution E2/ AS1, Paragraph 1.1; with regards to building height and floor plan area; and,</li> <li>With absorbent and non-absorbent wall claddings directly fixed to the frame; and,</li> <li>With absorbent and non-absorbent wall claddings installed over an 18mm minimum drained cavity; and,</li> <li>With masonry veneer in accordance with NZBC Acceptable Solution E2/AS1; and,</li> <li>Situated in NZS 3604 wind zones up to and including 'Very High'</li> </ul>
	<ul> <li>Barricade FR has been appraised for use as a flexible wall underlay over rigid wall underlays on timber and steel framed buildings within the following scope:</li> <li>The scope limitations of NZBC Acceptable Solution E2/ AS1, Paragraph 1.1; and,</li> <li>With absorbent and non-absorbent wall claddings installed over an 18mm minimum drained cavity; and,</li> <li>With masonry veneer in accordance with NZBC Acceptable Solution E2/Acceptable Solution E2/AS1; and,</li> <li>Situated in NZS 3604 wind zones up to and including 'Extra High'</li> </ul>
1.4 INSTALLATION	<ul> <li>&gt; Barricade FR must be fixed (with the printed side out) to all framing members at maximum 300 mm centres with largehead clouts 20 mm long, 6-8 mm staples, self drilling screws or proprietary underlay fixings. The membrane must be pulled taut over the framing before fixing.</li> <li>&gt; Barricade FR must be run horizontally and must extend from the upper-side of the top plate to the under-side of the bearers or wall plates supporting ground floor joists, or below bottom plates on concrete slabs. Horizontal laps must be no less than 75 mm wide, with the direction of the lap ensuring that water is shed to the outer face of the membrane. End laps must be made over framing and be no less than 150 mm wide.</li> <li>&gt; The wall underlay should be run over openings and these left covered until windows and doors are ready to be installed. Openings are formed in the membrane by cutting on a 45 degree diagonal from each corner of the penetration. The flaps of the cut membrane must be folded inside the opening and stapled to the penetration framing. Excess underlay may be cut off flush with the internal face of the wall frame. Masons Flashing Tape needs to be installed around the openings prior to fitting the doors and windows.</li> </ul>



This document is uncontrolled in printed form. See www.mpb.co.nz for current version. Copyright © 2024 Masons.